



Set Up Your GL.iNet Mudi with Airalo + Red.One VPN

Private global connectivity for hotspot and repeater use

Complete the device's initial setup first, then use the steps below.

TRAVEL
FREELY
STAY
PRIVATE



1 Mobile Hotspot (Airalo eSIM)

Share to your devices by Wi-Fi or USB-C



- 1 Buy and install an Airalo eSIM package.
- 2 In the router admin panel, go to Internet > Cellular > eSIM Management.
- 3 Add the Airalo eSIM profile and confirm cellular data is active.
- 4 Once the Mudi is online, connect your devices either to the Mudi Wi-Fi network or by USB-C.
- 5 If using USB-C, you can turn the Mudi Wi-Fi off and use it as a wired hotspot.

2 Add Red.One VPN



- 1 In the web admin panel, go to VPN > VPN Client Profile or WireGuard Client.
- 2 Choose "Add Manually."
- 3 Upload the supplied Red.One .conf file.
- 4 Connect the tunnel and confirm it shows "Active."
- 5 If available, enable Kill Switch for stronger protection.
- 6 Treat the VPN configuration as a private credential.

3 Repeater Mode + VPN



- 1 In Internet > Repeater, click "Connect."
- 2 Select the existing Wi-Fi network.
- 3 Enter the password and connect.
- 4 Keep the Red.One VPN active so connected devices stay protected.

Quick Checks

- Confirm internet first, then VPN.
- Reconnect the VPN after changing internet sources.
- Verify your devices are connected to the Mudi, not directly to public Wi-Fi.
- Use Wi-Fi or USB-C from the Mudi depending on your setup.

What This Does

- Creates a private router between your devices and the internet.
- Routes connected-device traffic through Red.One VPN when active.
- Lets you share connectivity by Wi-Fi, wired USB-C, or repeater mode.
- Helps protect traffic in transit on travel or public networks.